

A-TOUCH 1200

A-Touch 800



BIG BOSS BOSS/SC

mhx: 02.07.06.00
iop: 1.60

ECUs 2

Midi Version 3 / 02.07.06.00


(January 2022)

En / January 2022

2- A touch compture feature



- 1 Switch on/off button
- 2 Locking button or screenshot for USB
- 3 Function button



Option

1	<u>GSM antenna connection</u> Only in the case of device fitted out with a GSM modem.	6	<u>Protecting cap for USB port</u> It protects the USB port from the dust
2	Is not used for the moment	7	<u>SIM card spot</u>
3	<u>Analog camera connection</u> Only for the case of device fitted out with a GSM modem. Art – Nr. 30322527	8	<u>Connecting B</u> CAN-Bus connecting Refer to : <u>Broaching connecting B</u> (→79)
4	<u>Analog camera connection</u> Only in case of device fitted out with a GSM modem.	9	<u>Connecting A</u> Connecting CAN-Bus For the ISOBUS base's device connecting
5	<u>USB port</u> USB 1.1	10	<u>Connecting C</u> Serial port RS232 for : - GPS receiver - Tilt compensator « GPS Tilt module » - Guide bar

3 – Icones => DESIGNATION

Drawing for user :

Homepage :



Informations of area



Work position



On/OFF 'application




Parameter of tramline



Hopper Level down or empty




Manual modulation seeder



light



Parameter




On/off ramp




Pre start(s)


In others pages :



Next page




Products




To the top



Calibration acces



Confirmation




To the back



Starting calibration



Diagnostic



Width



Record calibration



product



Speed Parameter



Back




Parameter seeder

4 – CUT OUT + WORKING WIDTH

1 – On homepage , press button




2 – Page 1/3 – Press again button :



3 – Page 2/3 Press button



4 – Page 3/3 Press button



4 – CUT OUT + WORKING WIDTH

5 – Select this fonction if the machine have a cut out system

☐	Tractor
☒	Work Position Sensor 1
☐	No



6 – Back on the page 3/3, and Press again :

SETTINGS
3/3

Work Position

Work Position Sensor 1

7 – Modification of the boom 1.
Select the **working width**

GEOMETRY

Boom 1

Working Width

12.00 m

Delay on Start

0 ms

Delay on Stop

0 ms

Diagram

-5.00 m

0.00 m

8 - to define the working width

6.00 m

0 ms

Delay on Stop

12.00

Green checkmark

1

2

3

4

5

6

7

8

9

0.00

0

99.99


Red X

« Check the number of the boom. »

En / January 2022


4 – CUT OUT + WORKING WIDTH

9 – Modification of the boom 2. Press the button




Always check the working width when you coupling an other machine.
Do the same process for the other BOOM (until 4 BOOM)

10 – Modification of the boom 2. Select the **working width**.



« Check the number of the boom »


11 – To define the working width.




5 – User setup

Calibration of the radar


- 1 - To calibrate the radar, you need to trace 100 m precisely in the field.
- 2 – Put the machine in working position



- 3 – Press button




- 4 – To choose the speed. Press the button to select the radar or DGPS system.



5 – User setup

5 – Press the button




CALIBRATION

Mark a distance of 100m on the field.

ME

6 – Start the calibration of the speed sensor.



CALIBRATION

Now cover the distance and stop at the end.


2. Stop to stop press

No. of Impulses 0

ME

7 – Choose the speed

- Button 1, tractor
- Button 2, Radar or DGPS
- Button 3, simulation



CALIBRATION


Speed Source

Tractor

Confirm

Cancel

8 – To valid the system press the button



CALIBRATION

Speed

Speed Source

Simulation

Simulated Speed

0.0 km/h


Confirm

Cancel


ME

6- Product DataBase

1 – Homepage next press the button:




2 – Press again the button



3 – To define the hopper 1 at hopper 4, after press the button




4 – Select the product, and press the button



6- Product DataBase

5 – Parameter of the product, press the button.



PRODUCT DATABASE
wheat

Gear Ratio
1 / 1


Fan Speed Target Rate
4500 rpm

Fan Speed Tolerance
+ 25 % - 25 %

Fill Level Alarm Thresh.
Low/Empty

Deviation Tolerance
+ 15 % - 15 %

6 – Surface seeding



PRODUCT DATABASE
wheat


Area
0.00 ha

Quantity
0.00 kg

Area output
0.00 ha/h

Total Time
0:00 h:min

7 – Configuration rape « spécial configuration»



SETTINGS 1/3
ble


Product
ble

Target Rate
150.0 kg/ha

Status
Activated

Speed
min. 0.5 max. 0.0 km/h

8- To choose the rape product



☐ wheat

☐ engrais

☒ colza

☐ 4

☐ 5

☐ 6

6- Product DataBase

1- Press the next button.

PRODUCT DATABASE
rape

Product
rape

Renaming:
rape

Product Type
Seed

Note

Adjustment
10 %

2- To check the parameter of the product

PRODUCT DATABASE
rape

Gear Ratio
1 / 1

Fan Speed Target Rate
4500 rpm

Fan Speed Tolerance
+ 25 % - 25 %

Fill Level Alarm Thresh.
Empty

Deviation Tolerance
+ 15 % - 15 %

3- Working area information

BASE DONN. PRODUITS
Colza

Surface
0.00 ha

Volume
0.00 kg

Rendement surface
0.00 ha/h


Temps total
0:00 h:min

For the rape seeding , the alarm are not the same.
Only the sensor of the down are activated.

Fill level alarm thresh: Empty

6- Product DataBase

4- Creation new product.



PRODUCT DATABASE
wheat

Product
wheat


Renaming:
wheat

Product Type
Seed

Note

Adjustment
10 %

5 – Select one number



☒ **wheat**

☐ **engrais**


☐ **rape**

☐ **4**

☐ **5**

☐ **6**

6- To change the name



PRODUCT DATABASE
wheat

Product
wheat


Renaming:
wheat

Product Type
Seed

Note

Adjustment
10 %

7 – Write the name of the new product



wheat
Product Type
Seed

wheat

a b c d e f g h i j


k l m n o p q r s t

u v w x y z . A B

12# < > C D E F

6- Product DataBase

8 – Press the button to display all products.



PRODUCT DATABASE
18.46

Product
18.46


Renaming:
18.46

Product Type
Solid fertilizer

Note

Adjustment
10 %

9 – Select the product,



☒ **18.46**

☐ **rape**


☐ **4**

☐ **5**

☐ **6**

☐ **7**

10 – It's possible to change the alarm level.



PRODUCT DATABASE
18.46

Gear Ratio
1 / 1


Fan Speed Target Rate
4500 rpm

Fan Speed Tolerance
+ **25 %** - **25 %**

Fill Level Alarm Thresh.
Deactivated

Deviation Tolerance
+ **15 %** - **15 %**

11 – Level of Alarms.




☒ **Low/Empty**

☐ **Empty**


☐ **Deactivated**

7 – The Test Flow Motor (1) / 1-2-3 and 4


1- Press the button:




2 – Select the product of metering unit N°1



3- Select the product of metering unit N°1.




4 – Select the image following :




7 – The Test Flow Motor (1) / 1-2-3 and 4


5- Put the information needed :




6- This button is loading the stars during 10 secondes.



7- Select the Harrow to active the test flow.



8- The monitor arrives on this screen, then press the calibration button.



7 – The Test Flow Motor (1) / 1-2-3 and 4

9– Press the value to go enter the weight gotten.



10 – Enter the weight gotten.


11 – Check the maximum and minimum speed, if you have a bad speed you have to change the distribution star.




12 – The calibration factor changes after each test depending on the result got. The operation must be repeated as long as the weight obtained is not close to the weight theoretical (- 5% error). The speeds indicated are the limits of the working range of the distribution according to that configuration, modify it if the work does not match. Repeat the operation for the other engine.

7 – The Test Flow Motor (2) / 1-2-3 and 4


1- Press the button:




2 – Select the product of metering unit N°1



3- Select the product of metering unit N°1.




4 – Select the image following :




7 – The Test Flow Motor (2) / 1-2-3 and 4


5- Put the information needed :




6- This button is loading the stars during 10 secondes.



7- Select the Harrow to active the test flow.



8- The monitor arrives on this screen, then press the calibration button.



7 – The Test Flow Motor (2) / 1-2-3 and 4

9– Press the value to go enter the weight gotten.

CALIBRATION
3. Result

Weighed Value
0.872 kg

Calculated Value
0.872 kg

Deviation
0.0 %

Speed
min. 1.1 max. 7.1 km/h



10 – Enter the weight gotten.

2.600 kg
Calculated Value

0.000 kg

150

1 2 3
4 5 6
7 8 9
0.000 0 999.999

11 – Check the maximum and minimum speed, if you have a bad speed you have to change the distribution star.

CALIBRATION
1. Start


Speed
min. 1.1 max. 7.1 km/h




12 – The calibration factor changes after each test depending on the result got. The operation must be repeated as long as the weight obtained is not close to the weight theoretical (- 5% error). The speeds indicated are the limits of the working range of the distribution according to that configuration, modify it if the work does not match. Repeat the operation for the other engine.

10 - Tramlining


1 – On the homepage, Press the button



2 – Press the button to program the marking



3 – Parameter setting



4 – Select width and validate pressing on.



10 - Tramlining

Procedure :

Here is how to proceed to chose the rythm of the appropriate marking:

- ✓ You know the working width of your seeder
- ✓ You know the working width of our sprayer

1. Choose to start working from the left hand side or from the right hand side of the field.

2. Calculate:

working width of the sprayer / working width of the seeder

ex. : $12 : 3 = 4$; $15 : 3 = 5$ or $20 : 3 = 6,67$

⇒ The results beneath are possible:

pair numbers (2 ; 4 ; 6 ; etc.),

odd numbers (3 ; 5 ; 7 ; etc.)

decimal numbers (1,5 ; 4,5 ; 5,33 ; etc.)


⇒ You have to choose a different rythm of marking, depending on each result. You will find the results on the instructions of the pneumatic seeder.

10 – Tramlining / Passage of a sprayer in the middle of a passage of a seeder


5- For a 1st example, we will use a 21m sprayer and a 3m seeder, which makes $(21/3 = 7)$ 7 passages of seeder for 1 passage of sprayer




7 – Press on button 10 to come back to the main menu



6 – The left and right hand side valves will activate themselves at the 4th passage. Press on button




8 – At the 4th passage, the marking valves will activate themselves



10 – Tramlining / Passage of a sprayer in the middle of a passage of a seeder

3m seeder with a 15m sprayer
6m seeder Other example with a 30m sprayer


Other example



Control board



Tracer position



10 – Tramlining ½ seeder


5 bis – Start steps 1 to 4 again. For an example, let's take a 24m sprayer and a 3m seeder (24/3 = 8 passages). In this case, only one valve will be active.

Choose the side of the field you will start to select the right or left valve

If we start by the left side, we select the left valve.



Exemple



6 bis – Go on line 8G and validate

☒	Off					
☐	2	2	2	1	2	1
☐	2L	2	0	0	2	1
☐	2R	2	2	1	0	0
☐	3	3		2		2
☐	4	4	3	2	3	2




7 bis – The left valve will activate itself at 4th passage and 5th passage


0.0 km/h		1	
0 l/min		/ 8	
RÉGLAGES			
Jalonnages			
N°r.	Long.	Gauch	Drte
86	8	5	4 0 0
Indiv.	Long.	Gauch	Drte
	0	0	0 0 0

10 – Tramlining ½ seeder


8 bis – Homepage



9 bis – At the 4th passage, the left valve activate itself for the first time.




10 bis – At 5 th passage, the left valve activate itself for the second time




11 – Tramlining / Using


11- Press the button to access at the marking parameter




12- Press the button to have an extra passage manually.



13- Press the button to have one passage less manually.




14- Press the button to stop the marking.




12 – Manual Rate Modulation


1-Press the button to enter on the modulation parameter of the temporary quantity




2- Buttons permits to increase temporary the quantity of 10% with each impulsions.



3- Button 1 et 2 or permits to reduce temporary the quantity of 10% with each impulsions.




4- Normal quantity.




13 – Worked area information


1- homepage, Switch on the seeder




2 – When you have this picture, the seeder is active



3- Button permit to enter on information.




4- We can see the sowed area since the last reset. Press the next touch to reset.




14 – Information surface / Missions


5- The area has been resetting. To see the total area press this button.




6- On this screen, appears the total of different informations, with no reset allowed.



7- It's possible to have many surface informations for each seed.




8 – We can change te name.




16 – Mode diagnostic


1- To enter the diagnostic mode, on the main screen, press the button. The seeder have to be close




2 – Press again the button.



3 – Press the button (3rd time)




4 – Press the button to enter in the diagnostic mode.



16 – Mode diagnostic

Press the following key to go to the other pages

- Function 0



Touche 1 : Version number

Touche 2 : Reset to zero


Touche 3 : Next page

MA 15 : Motor 1

MA 41 : Motor 1

PS: To test the motor, put LS out value at 50 %. The motor has to turn at 50% of its capacity, so around 1125 Tr/min.

- Fonction 1



Touche 1 : Version number

Touche 2 : Reset to zero

Touche 3 : Next page


MA 28 : Motor 2

MA 35 : Motor 2

PS: To test the motor, put LS out value at 50 %. The motor has to turn at 50% of its capacity, so around 1125 Tr/min.

16 – Mode diagnostic

• Fonction 2



Touche 1 : Version number

Touche 2 : Reset to zero

Touche 3 : Next page


1S41 : Motor 3

1S15 : Motor 3

2 PS: To test the motor, put LS out value at 50 %. The motor has to turn at 50% of its capacity, so around 1125 Tr/min.

3

• Fonction 3



Touche 1 : Version number

Touche 2 : Reset to zero

Touche 3 : Next page

1S35 : Motor 4

1S28 : Motor 4


PS: To test the motor, put LS out value at 50 %. The motor has to turn at 50% of its capacity, so around 1125 Tr/min.

2

3

16 – Mode diagnostic

• Fonction 12




Touche 1 : Version number

Touche 2 : reset to zero

Touche 3 : next page

MA 38 : Fan

• Fonction 16



Touche 1 : Version number


Touche 2 : reset to zero

Touche 3 : next page

MA 30 : Radar or DGPS

16 – Mode diagnostic

• Fonction 17




Touche 1 : Reset to zero

Touche 2 : Next page

MA 22/23 : Tramline

• Fonction 18




Touche 1 : Reset to zero

Touche 2 : Next page

MA 20/MA21 : Tramline

16 – Mode diagnostic

- Fonction 31




Touche 1 : reset to zero

Touche 2 : next page

1S39 : Cut off

- Fonction 35




Touche 1 : reset to zero

Touche 2 : next page

1S37 : Low level sensor of the hopper N°3.

16 – Mode diagnostic

- Fonction 36




Touche 1 : reset to zero

Touche 2 : next page

1S 2 : Empty level sensor of the hopper N°4, (Small tank)

- Fonction 37




Touche 1 : reset to zero

Touche 2 : next page

1S36 : Low level sensor of the hopper N°4 (Small tank)

16 – Mode diagnostic

- Fonction 93




Touche 6 : reset to zero

Touche 9 : next page

MA 34 : **Yellow** Button of calibration

- Fonction 94




Touche 1 : reset to zero

Touche 2 : next page

MA 3 : Empty level sensor of the hopper N°1

16 – Mode diagnostic

- Fonction 95



Touche 1 : reset to zero


Touche 2 : next page

MA 26 : Beacon 1



16 – Mode diagnostic

- Fonction 96




Touche 1 : reset to zero

Touche 2 : next page

MA 27 : Beacon 2

- Fonction 97




Touche 1 : reset to zero

Touche 2 : next page

MA 7 : Working Light 1

16 – Mode diagnostic

- Fonction 98




Touche 1 : reset to zero

Touche 2 : next page

MA 5 : Working Light 2

- Fonction 99




Touche 1 : reset to zero

Touche 2 : next page

MA 37 : Low level sensor of the hopper N°1.

16 – Mode diagnostic

- **Fonction 100**




Touche 1 : reset to zero

Touche 2 : next page

MA 2 : Empty level sensor of the hopper N°2.

- **Fonction 101**




Touche 1 : reset to zero

Touche 2 : next page

MA 36 : Low level sensor of the hopper N°2.

16 – Mode diagnostic

- Fonction 102




Touche 1 : reset to zero

Touche 2 : next page

1S26 : Beacon 3

- Fonction 103




Touche 1 : reset to zero

Touche 2 : next page

1S07 : Working Light 3

16 – Mode diagnostic

- Fonction 104



Touche 1 : reset to zero

Touche 2 : next page

1S03 : Empty level sensor of the hopper N°3.

Master

Slave

Hopper N° 1 :

Low : S3 / MA37

Empty : S4 / MA3

Hopper N° 3 :

Low : S3 / 1S37

Empty : S4 / 1S03

Hopper N° 2 :

Low : S1 / MA36

Empty : S2 / MA2

Hopper N° 4 : (Small)

Low : S1 / 1S36


Empty : S2 / 1S02

16 – Mode diagnostic

Recap :

Functions		Functions	
0	MA 15 : Motor 1 MA 41 : Motor 1	93	MA 34 : Calibration button
1	MA 28 : Motor 2 MA 35 : Motor 2	94	MA 3 : Hopper sensor Empty level 1
2	1S 41 : Motor 3 1S 15 : Motor 3	95	MA 26 : Rotating light No. 1
3	1S 35 : Motor 4 1S 28 : Motor 4	96	MA 27 : Rotating light No. 2
12	MA 38 : Turbine	97	MA 7 : Working light N°1
16	MA 30 : Radar (speed camera)	98	MA 5 : Working light N°2
17	MA 22/23 : Gauge Valve	99	MA 37 : Hopper sensor Low level 1
18	MA 20/MA 21 : Gauge Valve	100	MA 2 : Hopper sensor Empty level 2
31	1S 39 : Working position sensor	101	MA 36 : Hopper Sensor Low Level 2
35	1S 37 : Hopper Sensor Low Level 3	102	1S 26 : Rotating light No. 3
36	1S 2 : Hopper sensor Empty level 4 (small hopper)	103	1S 7 : Working light N°3
37	1S 36 : Hopper Sensor Low Level 4 (small hopper)	104	1S 3 : Hopper sensor Empty level 3

17 – Mounting mode = Junction box table



17 – Mounting mode = Junction box table

ECU 1 = Master

ACTIONS	1 PARTS	GNDL = neutre										
		12 VL										
		A 19	A17	A15	A13	A 11	A9	A 7	A 5	A 3	A 1	
		Motor 2 A19 & S17* (12v+sig)	Beacon 1		Tramline left	Tramline right				Light 2	Light 1	
	2 PARTS	GNDL = neutre										
		12 VL										
		A 20	A 18	A 16	A 14	A 12	A 10	A 8	A 6	A 4	A 2	
		Motor 2 A20 & S24* (12v+sig)	Beacon 2		Tramline left	Tramline right						
CAPTEURS	S 23	S21	S 19	S 17	S 15	S 13	S 11	S 9	S 7	S 5	S 3	S 1
				Metering drive 1* encoder							Low level sensor hopper 1	Low level sensor hopper2
	12 VE											
	GNDE = neutre											
	S 24	S 22	S 20	S 18	S 16	S 14	S 12	S 10	S 8	reserve	S 4	S 2
	Metering drive 1 * encoder		Fan speed sensor 1		Calibration switch/ unload switch	Vehicule speed sensor					Empty level sensor hopper 1	Empty level sensor hopper 2
	12 VE											
	GNDE = neutre											



17 – Mounting mode = Junction box table

ECU 2 = Slave


ACTIONS	1 PARTS	GNDL = neutre										
		12 VL										
		A 19	A 17	A 15	A 13	A 11	A 9	A 7	A 5	A 3	A 1	
		Motor 4 A19 & S17* (12v+sig)	Beacon 3							Light 3		
	2 PARTS	GNDL = neutre										
		12 VL										
A 20		A 18	A 16	A 14	A 12	A 10	A 8	A 6	A 4	A 2		
		Motor 3 A20 & S24 * (12v + TB) reverse polarity										
CAPTEURS	S 23	S21	S 19	S 17	S 15	S 13	S 11	S 9	S 7	S 5	S 3	S 1
		Work position sensor		Metering drive 4* encoder							Low level sensor hopper 3	Low level sensor hopper 4
	12 VE											
	GNDE = neutre											
	S 24	S 22	S 20	S 18	S 16	S 14	S 12	S 10	S 8	reserve	S 4	S 2
	Metering drive 3 * encoder				Calibration switch/ unload switch						Empty level sensor hopper 3	Empty level sensor hopper 4
	12 VE											
GNDE = neutre												

17 – Mounting mode = Junction box table


Power BOX



17 – Mounting mode = Junction box table



17 – Mounting mode = Junction box table




17 – Mounting mode = Junction box table

Couleurs colliers		Désignation
JAUNE		Work position sensor
BLEU	ROUGE	/
BLEU	NOIR	/
JAUNE	VERT	Hopper high level sensor - Hopper 1 and 3
JAUNE	BLEU	Hopper high level sensor - Hopper 2 and 4
JAUNE	ROUGE	Hopper low level sensor - Hopper 1 and 3
JAUNE	NOIR	Hopper low level sensor - Hopper 2 and 4
ROUGE		Turbine speed sensor
VERT		Calibration button
BLEU		Radar or GPS
ROUGE	VERT	Motor 1 and 3
ROUGE	NOIR	Motor 2 and 4
BLANC		Working lights

17 – Mounting mode = Junction box table


- Take care when connecting the motor wires, they must always be connected in this order:

Colour	Terminal
Red	12VL
Blue	Sig
Green	Sig
Brown	12VE
White	0VE



- The hopper sensors are connected to S1/ S2/ S3 and S4

Colour			Terminal
Black	or	Green	Sig
Brown			12VE
Blue	or	Red	0VE



17 – Mounting mode = Junction box table


1 - Turbine sensor position

Dimension to be observed = 44 mm at the end of the sensor on the motor support bracket




2 - 2 motor harness wiring

- 1 and 2 = + (blue)
- 3 = 0 VE (brown)
- 4 = 12 VE (white)
- 5 and 6 = - (red)
- 7 = Signal (green)



NOTT-0163

3 - Check that the 10 A fuse is compliant. This fuse serves to protect the motor.



NOTT-0168

17 – Mounting mode = Junction box table

Message	Possible cause	Remedial solution
Metering drive speed too slow	The current metering drive speed of rotation is lower than the minimum speed.	Stop immediately!
		Eliminate the cause of the problem.
Metering drive speed too fast	You are travelling too fast. The metering drive cannot operate reliably at your speed of travel.	Travel more slowly or install a larger metering roller.
The metering drive cannot achieve the target rate	You are travelling too fast or too slowly. The target rate cannot be achieved at your current travel speed.	Travel faster or slower for the computer to control the specified application rate.
Metering drive outside adjustment range	The current metering drive speed of rotation is higher or lower than the predefined speed.	Travel slower or faster or install a larger metering roller.
Metering shaft stopped	The metering shaft rotation speed sensor no longer detects any shaft movement.	Stop immediately!
		Eliminate the cause of the problem.
Turbine too slow	Current turbine speed of rotation is lower than the value of the “Min revs” parameter value.	Increase the turbine speed of rotation or change its “Min rev.” parameter.
Turbine too fast	Current turbine speed of rotation is higher than the value of the “Max revs” parameter value.	Reduce the turbine speed of rotation or change its “Max rev.” parameter.

17 – Mounting mode = Junction box table

The pressure is too high	The pressure of a linear sensor is higher than the value of the “Maximum value” parameter.	Reduce the pressure or change the “Maximum value” parameter.
The pressure is too low	The pressure of a linear sensor is lower than the value of the “Minimum value” parameter.	Increase the pressure or change the “Minimum value” parameter.
Hopper tank level too low	There is too little seed or fertiliser in the hopper.	Fill the hopper.
Empty hopper	There is no seed or fertiliser in the hopper.	Fill the hopper.
Seeding controller error	A error has occurred in the seeding control system.	Check the seeding control system.
Seed flow rate detected	There is a seed flow rate in a tramline.	Check the tramlining system.
No seed flow rate detected	The seeding control system has detected no seed flow rate.	Check the seeding control system.
Input too high	The value input is too high.	Enter a lower value.
Input too low	The value input is too low.	Enter a higher value.
Charger anomaly	The charger alternator is faulty.	Check the charger alternator.
Metering has been stopped as the working position was not achieved. Lift the machine.	The machine is not in the working position.	Lift the machine.