
Disc wear and seed boot adjustment for BOSS

new disc/hub dimension 148 mm



Disc wear/hub dimension >140 mm: move seed boot to the high position

